



Aqua-Cycle International, Inc.

Ride a Tricycle on Water

SEAT & SEAT STRAP ASSEMBLY

These instructions are to serve as a guide when replacing the Aqua-Cycle seat or seat straps. Please read this complete sheet before securing the seat to the frame.

The seat is held in place by four specially designed straps. These straps are inserted through the holes in the seat legs and tightened around the frame.

The seat's rear legs allow for two placements or adjustments of the seat. Most often you should place the seat in the forward most position to accommodate people with medium to short legs.

Put straps on the rear legs first and then the front legs. Do not insert the strap end into the strap head or tighten it until all four straps are pushed through the seat leg holes.

The rear legs are difficult to get the straps through. Looking at one rear leg, locate the rear hole (hole 1) and the next hole (hole 2) just forward of that. It works best to insert one strap (let's call it strap A) into hole 2 and then push another strap (strap B) through from hole 1. Strap B will hit strap A (which serves as a guide or path to hole 2 for strap B) and strap B can then be guided to and pushed out through hole 2. Remove strap A, but do not secure or tighten strap B at this time. Now repeat the process on the other rear seat leg, but do not secure or tighten it.

Once the two rear leg straps are through the holes insert the remaining straps into the front leg holes.

Assuming that the seat is in place and all four straps are through the holes in the seat legs, now go ahead and push the end of the each strap through the head and pull, but not so tight that the strap is stressed. The seat needs to be held in place on the frame, but if the strap is too tight it will eventually break or be damaged. Now push the end of the strap through the extra loop on the head to secure it further and pull it tight. Push the remaining portion of the end into the nearest seat leg hole to keep it out of the way.

May 23, 2006-AC Seat & Seat Strap Assembly

Post Office Box 2129 • Yorba Linda, CA 92885-1329

Voice: 800-970-2688 • Fax: 888-970-0467 • Internet: www.aqua-cycle.com